

TT-DCT55 Quick Guide

QUICK GUIDE FOR TITAN 5500 (DUAL SESSION) SWITCH ACCESS TERMINALS

CONTENTS:


TITAN 5500 SWITCH ACCESS TERMINAL CONFIGURATION	Page 1
TERMINAL COMMAND KEYS	Page 2
GENERAL SETTINGS NOTE	Page 3
TERMINAL SETUP	Page 4
CHANGING THE SERIAL PORT SETTINGS	Page 5
CHANGING THE SCREEN DISPLAY TO FULL OR SPLIT SCREEN	Page 6
PROGRAMMING FUNCTION KEYS	Page 7
CHANGING THE SCREEN TITLE	Page 8
TITAN 5500 DEFAULT SETTINGS	Page 9



TT-DCT55 Quick Guide

TITAN 5500 SWITCH ACCESS TERMINAL CONFIGURATION


FIGURE 1



TT-DCT55 Quick Guide

TERMINAL COMMAND KEYS

FIGURE 2



SWITCH SESSIONS (for dual sessions only)	<p>Press Ctrl + Enter <i>(Enter on the Number Pad)</i></p>
PRINT	<p>Press Ctrl + Shift + • <i>(Decimal on the Number Pad)</i></p>
SEND BREAK	<p>Press Ctrl + Pause/Break Key</p>

TT-DCT55 Quick Guide



GENERAL SETTINGS NOTE

Terminals are supplied pre-configured for your Titan 5500 switch. Some local settings may need to be adjusted. Example: Baud Rate, Function Keys etc.

The following pages show how to make adjustments to the terminal when required.

TT-DCT55 Quick Guide

TERMINAL SETUP

FIGURE 3**FIGURE 4**
**ENTER
SETUP SCREEN**


 Press **Ctrl + Scroll Lock**


SELECT MENU	Press F1 - Prt Scn (see pg.9 for Titan 5500 Default Setup)	F1 F2 F3 F4 F5 F6 F7 F8 F9 F10 F11 F12 Prt Scn SysRq
NAVIGATE PARAMETERS	Press the Arrow Keys	
NAVIGATE CHOICES	Press Enter or Spacebar (moves forward)	
	Press Shift + Enter (moves backward)	
EXIT SETUP SCREEN	Press the Pause Key (when prompted to "Save all", press Y key to Save or N key to discard)	
	Pause Break	

TT-DCT55 Quick Guide

CHANGING THE SERIAL PORT SETTINGS

FIGURE 5



1. Press the **F1** button
2. Use the **Arrow Keys** to move to **SER1 Baud Rate (SER1 = Serial Port 1)**
3. Press **Enter** or **Spacebar** until the correct **Choice** is highlighted (9600 for Titan 5500)
4. Use the **Arrow Keys** to move over to **SER1 Data Format**
5. Press **Enter** or **Spacebar** until the correct **Choice** is highlighted (8/1/N for Titan 5500)
6. When finished, press the **Pause Key** at the top right of the keyboard
7. When prompted with "**Save all?**", click **Y** to save the new **Parameters**


TT-DCT55 Quick Guide

CHANGING THE SCREEN DISPLAY TO FULL OR SPLIT SCREEN*

***Note:** Applies to dual sessions only


("Sessions" in F1 must be set to "Two" first - see Session setting in Figure 5).

FIGURE 6



1. Press the **F3** button
2. Use the **Arrow Keys** to move over to **Session Display**
3. Press **Enter** or **Spacebar** until the correct **Choice** is highlighted (Full / Split)

FIGURE 7




4. Press the **F3** button
5. Use the **Arrow Keys** to move over to **Screen Length**
6. Press **Enter** or **Spacebar** until the correct **Choice** is highlighted (49 Lines for Split Screen)
(26 Lines for Full Screen)
7. When finished, press the **Pause Key** at the top right of the keyboard
8. When prompted with "Save all?", click **Y** to save the new **Parameter**

TT-DCT55 Quick Guide

PROGRAMMING FUNCTION KEYS*

*Each function key has (4) programmable registers per session such as **F/key**, **sh-F/key**, **ctrl-F/key** & **ctrl-sh-F/key**
 (These can be selected from the "Choices" located in the "**Program**" Parameter)




1. Press the **F12** button
2. The cursor will appear in the "Key" Field with F1 as the default
3. Select a new function key to program by pressing **Enter** or **Spacebar** until the correct **Choice** is highlighted (for example choose F6)
4. Arrow down to move to the "Text" Field
5. Type in the "Function" for the key. **CAUTION:** The first character in the Text Field cannot be left blank
Example: To program **ESC[17~** Type: **Shift+6** **[[17** **Shift+`** = (^[[17~)
Note: For ^ press Shift+6
6. To program another function, arrow back up to the "Key" Field & repeat steps 3-5
- 6A. **Note:** An example of a typical login command function programmed for "F1" is:

```
act-user:::tellabs:FL:::tellabs#1;
  ("FL" is the user's initials)
```
7. When finished, press the **Pause Key** at the top right of the keyboard
8. When prompted with "Save all?", click **Y** to save the new **Parameter**

TT-DCT55 Quick Guide

CHANGING THE SCREEN TITLE

Note: This will change the title at the top of the Session.



DISPLAY ON MONITOR

FIGURE 9

The screenshot shows a terminal window with a menu bar and several configuration options. The menu bar includes F1 through F12 keys and a PrtSc Exec key. The main area has sections for 'Parameters', 'Save all? (Y/N)', 'Answerback Mode=Off', 'Answerback Conceal', 'Answerback Message:', 'Screen Title:' (containing 'TT-DCT55 1'), 'Choices', and keyboard shortcuts. Numbered circles (1-5) highlight specific elements: 1 points to the F11 key; 2 points to the 'Screen Title:' field; 3 points to the text 'TT-DCT55 1'; 4 points to the 'Select' button; and 5 points to the 'Save all?' prompt.

1. Press the **F11** button
2. Use the **Arrow Keys** to move the cursor down to **Screen Title**
3. Type in a Title for the Session (Example: TT-DCT55 1)
4. When finished, press the **Pause Key** at the top right of the keyboard
5. When prompted with "**Save all?**", click **Y** to save the new **Parameters**

TT-DCT55 Quick Guide

TITAN 5500 DEFAULT SETTINGS*

***Note:** When using Dual Sessions, parameters must be set for both sessions.

Note: Items in **Bold** may require Local Settings.

FIGURE 10

Menu	Key	Parameters Available (Not all will display for a given emulation, keyboard, or video mode)		
Quick	F1	Emulation = VT-100 Comm Mode = Full Duplex Enhanced = On Host/Printer = SER1/Para SER2/Para	SER1 Baud Rate = 9600 SER2 Baud Rate = 9600 Language = U.S.	SER1 Data Format = 8/1/N SER2 Data Format = 8/1/N Sessions = One
General	F2	Emulation = VT-100 Screen Saver = 5-min Warning Bell = On Host/Printer = SER1/Para SER2/Para	Enhanced = On Auto Page = Off Bell Length = 350 ms Sessions = One	Auto Wrap = Off Auto Scroll = On Bell Volume = 5 Session Display=Full
Display	F3	Page Length = 24 Display Cursor = On Columns = 80	Screen Length = 26 Lines Cursor = Blink Block Erase Color = Black	Screen Video = Normal Auto Adjust Cursor = On Scroll Speed = Full
Keyboard	F4	Language = U.S. Key Click = On Num Lock = Toggle	Char Set Mode = ANSI Key Repeat = Off Key Lock = Reverse	Margin Bell = Off Key Rate = 20 cps Caps Lock = Toggle
Keys	F5	Enter Key = <CR> Alt Key = Compose UDKS = Emul Dependent	Return Key = <CR> Disconnect = Pause	Backspace = <BS>/ Return Key Repeat = Off
Ports	F6	SER1 Baud Rate = 9600 SER2 Baud Rate = 9600 SER1 Xmt = Xon-Xoff SER2 Xmt = Xon-Xoff SER1 Break = 250 ms SER2 Break = 250 ms	SER1 Data Format = 8/1/N SER2 Data Format = 8/1/N SER1 Recv = Xon-Xoff(XPC) SER2 Recv = Xon-Xoff(XPC) SER1 Modem Control = Off SER2 Modem Control = Off	SER1 Parity Check = Off SER2 Parity Check = Off SER1 Xmt Pace = Baud SER2 Xmt Pace = Baud SER1 Disconnect = 2 sec SER2 Disconnect = 2 sec
Host	F7	Comm Mode = Full Duplex Recv = Ignore Send Region = Screen	Local = Off Null Suppress = On Send End = Region	Recv <CR> = <CR> Send Block Term = None
Print	F8	Prnt Mode = Normal	Prnt Region = Screen	Prnt Block = None
Emulation	F9	Numeric Kpd = Numeric ANSI-ID = VT320 Status Line = Indicator	Cursor Kpd = Cursor Feature Lock = Off	Send Data = All Function Key Lock = Off
Tabs	F10	Auto Init Tabs = Off	Default Tabs	
Answerback	F11	Answerback Mode = Off	Answerback Conceal	
Program	F12	Key = F1	Program = F/Key	Key Dir = Comm Dependent
Execute	Prt Sc	Save Terminal Save Session Reset Terminal Clear Screen Terminal Version	Recall Terminal Recall Session Reset Session Default Session UDKS	Default Terminal Default Session Reset Ports Update Terminal
Exit Setup	Pause	Save all? (Y/N)		

SER1 = SERIAL PORT 1

SER2 = SERIAL PORT 2