Fujitsu®FLASHWAVE®4100 Test Kit — KIT-FUJ4100

ST-FUJ4100DS1
FLASHWAVE 4100 DS1 Streaker Card w/ LED's
Wiring continuity via LED's for the 14 DS1 Circuits

TB-FUJ4100DS1
FLASHWAVE 4100 DS1 Test Board w/ Bantam Jacks
Test Access to the 14 DS1 Circuits

TB-FUJ4100DS3
FLASHWAVE 4100 DS3 Test Board w/ 440A Jacks
Test Access to the 4 DS3 Circuits

STB-FUJ4100BITS
FLASHWAVE 4100 BITS Streaker Card w/ LED's & Bantam Jks
Test Access for the BITS Slots

(1) 400210RD
Bantam to Bantam DS1 Test Cord (Tx) - Red, (6')

(1) 400210BK
Bantam to Bantam DS1 Test Cord (Rx) - Black, (6')

(1) P-2000X
Protected (-48V) Test Probe w/ LED, (6')

(1) 400409
Continuity Ground Cord, Pin Plug to Alligator, (6')

(1) 400210ARD
Bantam to Alligator Clips DS1 Test Cord - Red, (6')

(1) 400210ABK
Bantam to Alligator Clips DS1 Test Cord - Black, (6')

(1) 400440ARD
440A to 440A DS3 Test Cord (Tx) - Red, (6')

(1) 400440ABK
440A to 440A DS3 Test Cord (Rx) - Black, (6')

INCLUDES RUGGED 13" (H) x 20" (L) CARRYING CASE

(1) 600209F
Carrying Case

Ordering Information:

KIT-FUJ4100   Fujitsu FLASHWAVE 4100 Installation Test Kit   Call for Pricing
* Includes: (1) ST-FUJ4100DS1, (1) TB-FUJ4100DS1, (1) TB-FUJ4100DS3,
(1) STB-FUJ4100BITS, (1) 400210RD, (1) 400210BK, (1) 400210ABK, (1) 400409,
(1) 400210ARD, (1) 400440ARD, (1) 400440ABK, (1) P-2000X & (1) 600209F