

Connect RHTAS to a Soneplex System

INSTALLING SONEPLEX ADAPTERS:

Install TAG PN # RH-SPSNPX25-03 Adapter on all predetermined Soneplex shelves. The RH-SPSNPX25-03 plugs into the DB25F connector labeled PORT 2 RS-232 DTE on backplane of the Soneplex shelf (see below). Use a Cat 5 cable to connect the adapter to the RHTAS system. When provisioning the RHTAS system, set the Soneplex to Code Map Type "F" (RAW PORT) - see Section 4 (Setup & Configuration) in the RHTAS User Guide.

